

CKM SCRF Cavity

Microphonics Detuning Compensation and Thermometry Developments

Contributors

- Beams Division

- Leo Bellantoni
- Tim Berenc
- Al Beutler
- Helen Edwards
- Moyses Kuchnir
- John Reid
- Allan Rowe

- Technical Division

- Ruben Carcagno
- Steve Helis
- Timergali Khabiboulline
- Andrezj Makulski
- Roger Nehring
- Darryl Orris

References


- **Piezo Tuner**



- L. Lilje, S. Simrock, D. Kostin, “Characteristics of a Fast Piezo-Tuning Mechanism for Superconducting Cavities,” EPAC 2002, Paris, France.
- M. Liepe, W. Moeller, S. Simrock, “Dynamic Lorentz Force Compensation with a Fast Piezotuner,” PAC 2001, Chicago.

- **Thermometry**

- J. Knobloch, H. Muller, H. Padamsee, “Design of a High-Speed, High-Resolution Thermometry System for 1.5 GHz Superconducting Radio-Frequency Cavities,” Review of Scientific Instruments 65(11), 1994.
- T. Junquera, A. Caruette, M. Fouaidy, Q. Shu, “Surface Scanning Thermometers for Diagnosing the Tesla SRF Cavities,” PAC 1995

Some CKM SCRF Cavity Parameters

- Frequency: 3.9 GHz
 - Cells/cavity: 13
 - Cavity Length: 660 mm
 - $Q_{\text{ext}} = 6 \times 10^7$
 - Bandwidth (f / Q_{ext}): 65 Hz
- 
- The technical drawing on the right illustrates the physical structure of the linear accelerator. The top portion is a cross-sectional view of the cavity, showing two parallel cylindrical sections with a gap between them. Dimensions are provided for various components: a total length of 62.8 mm, a central gap of 33.0 mm, and individual section lengths of 18.0 mm, 30.0 mm, and 19.0 mm. The bottom portion is a side view showing the beam path as a series of connected loops, with a vertical dimension of 10.0 mm indicated for the central section.



Detuning Tolerance Target

- To keep RF power requirements low, it is desirable to keep the resonance frequency within $\sim 1/10^{\text{th}}$ of the bandwidth:

$$\frac{P_{comp}}{P_{(\Delta f=0)}} = \frac{1}{4} \left[\frac{\Delta f}{f_{1/2}} \right]^2 \quad f = 3.9 \text{ GHz} \pm 6.5 \text{ Hz}$$

- From Finite Element Analysis models, $\pm 6.5 \text{ Hz}$ corresponds to $\pm 3.1 \text{ nm}$ in a 13-cell CKM cavity length.
- Failure to achieve this detuning tolerance target would require de-Qing the cavity further to increase its bandwidth, thus increasing the RF power cost.

Detuning Contributions

- Lorentz Force Detuning
 - The rf magnetic field in a cavity interacts with the rf wall current resulting in a Lorentz force which can cause a small deformation of the cavity shape resulting in a shift of the cavity resonant frequency.
 - Important at high fields and for a pulsed accelerator such as TESLA.
- Microphonics Detuning
 - Thin-walled, narrow-bandwidth superconducting cavities are sensitive to mechanical vibrations in the acoustic range from pumps, compressors, etc.

Detuning Compensation

- Microphonics detuning is the main concern for CKM cavities. Lorentz force detuning is less of a concern because of the relatively long OFF (2 sec), long ON (1 sec) operating cycle. It is more of a concern for pulsed cavities such as TESLA (950 μ s flattop, 5 to 10 Hz repetition rate).
- The stepping motor used for fine cavity tuning cannot respond fast enough for active microphonics detuning compensation.
- A fast Piezo Actuator has been demonstrated to be a good candidate for dynamic Lorentz force detuning compensation. This application relies on the high repetitive characteristics of this type of detuning.
- We are investigating using a Piezo Actuator for random microphonics detuning compensation.

Piezo Actuator




Fig. 5: Displacement/voltage diagram of a typical piezostack for different voltage levels (within U_{max}). U_{ret} returnpoint of voltage for the individual cycle.




Fig. 3a: Piezoactuator with casing with internal mechanical prestress





Fig. 1: Principle design of a piezostack actuator



Piezo Actuators




Piezo Actuator Selection


- For prototype studies, we selected the Piezo Actuator P-206-40 from Piezosystem Jena. Some of its parameters are:
 - Bare piezostack compatible with cryogenic operation in liquid helium.
 - Voltage range: -10V to 150V
 - Range of motion (room temperature): 80 μm . At 1.8 K: ~ 8 to 10 μm
 - Length: 90 mm
 - Stiffness: 12 N/ μm
 - Maximum Load: 1000 N
 - Capacitance: 8500 nF

3-cell prototype instrumentation


- 3-cell prototype showing location of piezo element plus thermometry rings.
- Piezo element was used both as a sensor and as an actuator.




3-cell Mechanical Resonance




3-cell Mechanical Resonance FFT




Microphonics FFT - High Amplitude ($\sim \pm 550$ Hz)



Microphonics FFT – Low Amplitude ($\sim \pm 100$ Hz)




Microphonics FFT – All Pumps OFF




Microphonics – Dewar Support Modifications


(Measurements by T. Khabibouline, April 2003)





Piezo-RF Phase Error Transfer Function



RF Phase Error With Piezo Actuation



Manual Detuning Compensation




Microphonics detuning was reduced from ± 375 Hz to ± 175 Hz. Manual compensation is difficult because frequency, amplitude, and phase must be adjusted. In addition, only one sine frequency was used to drive the piezo actuator.

13-cell Vibration Measurements


- Piezo Actuator and Piezo Sensor at each end.
- Accelerometer at cells #1, #4, and #7.
- Frequency sweep: 20 Hz to 300 Hz in 20 seconds.




13-cell Vibration Measurements Results




13-cell Mechanical Resonances




Longitudinal Mode, Fixed Ends, accelerometer at mid-cell location
Sample Rate: 720 Hz




FFT Longitudinal Mode, Fixed Ends, accelerometer at mid-cell location
Sample Rate: 720 Hz



13-cell cavity tuner



13-cell cavity tuner cross section




Piezo Tuner Control

- Transfer Function measurements show a large number of modes with a large phase shift of several hundred degrees over the frequency range of interest. This makes feedback for microphonics control using the RF signal not possible with the piezo actuator.
- We are investigating applying adaptive feedforward control with algorithms typically used for noise or vibration cancellation such as the LMS filter.
- The CKM cavity operating cycle (1 sec ON, 2 sec OFF) would make it possible for these types of algorithms to adapt to microphonics perturbations during the beam OFF phase.

Adaptive Feedforward Control

- LMS Algorithm



The output of the filter is:


$$y(n) = w^T(n) x(n)$$

Where $w(n) = [w_0 \ w_1 \ \dots \ w_{M-1}]^T$ is the *weight vector* at time index n and $x(n) = [x(n) \ x(n-1) \ \dots \ x(n-M+1)]^T$ is the data vector of the M most recent input samples. The weight vector is adjusted each iteration according to equation:

$$w(n+1) = w(n) + 2u \ x(n)e(n)$$

Where u is a *convergence factor* the value of which affects the amount the weight vector is altered on each iteration.

LMS applied to CKM cavity (preliminary)




- This approach assumes the microphonics spectrum remains more or less constant between samples.
- Samples of the microphonics spectrum can be taken while the beam is OFF and then replayed to provide x_n . However, RF power is required for this measurement.


Active Noise Cancellation with Adaptive LMS Filter

Concept Demonstration


- The LMS filter was implemented to cancel noise from a source speaker in a duct using a compensating speaker.
- The algorithm was programmed in a real-time VxWorks operating system. The signals were acquired with a VME-based data acquisition hardware.



Noise Cancellation Results



Noise Cancellation Adaptation Details





Path Forward

- Demonstrate automatic microphonics detuning compensation in the 3-cell prototype using an FPGA board programmed with the adaptive feedforward LMS algorithm.
- 13-cell cavity measurements in operating conditions (e.g., mechanical resonances, piezo-rf transfer function, uncompensated microphonics)
- Characterization of the high-load piezo actuator to be used in the 13-cell cavity.
- 13-cell cavity measurements automatic compensation: strategy, fine-tune algorithm, etc.
- Packaging for production.

Cavity Thermometry - General


- Cavity surface thermometry is used to study local distribution of various types of energy losses and identify defects.
- Main types of cavity loss mechanisms:
 - Thermal breakdown (related to surface magnetic field)
 - Field emission (related to surface electric field)
- The temperature sensing element is usually Allen-Bradley carbon resistors encased in epoxy to prevent excessive cooling of the thermometer by the helium bath.
- Fixed or rotating arrays of thermometers have been used.

Example: 1.5 GHz Cavity (Cornell)





CKM Cavity Thermometry

- Small Iris size (30 mm) makes it difficult to use the general approach used in other cavities with Allen-Bradley carbon sensors. A smaller CERNOX sensor was used instead.




- The sensor was attached with epoxy to a spring-loaded G-10 stick, and an Indium half-sphere was glued to the tip of the CERNOX sensor and covered with Apiezon grease prior to installation to improve thermal contact.

CKM Cavity Thermometry




Thermometry DAQ System

- A fast (KHz) CERNOX readout system is required to capture surface T during cavity quench.
- Available systems (commercial or in-house) were too slow (a few samples per second)
- We designed a system based on a Keithley precision current source, an in-house amplifier designed for this application, and a 16-bit, 100 kHz ADC card.




In-house amplifier



- To avoid self-heating, CERNOX RTDs must be driven with a very low current ($< 0.5 \mu\text{A}$).
- The resulting RTD voltage is typically a few mV. Filtering and amplification is needed before digitizing the signal.
- To avoid errors, an ultra low input bias current instrumentation amplifier ($< 3 \text{ fA}$) such as the INA116 is required.



Self-Heating Study




Cavity Quench Thermometry




Cavity cw thermometry at two different polarizations

CW Data, Polarization Mode I, 0.5 μ A RTD current



CW Data, Polarization Mode II, 0.5 μ A RTD current



Path Forward

- We need to scale up the thermometry system for the 13-cell cavity.
- Software for automatic data reduction and analysis has to be written.