

# Low Beta Turn on Checklist, via JAVA

CDF	D0	What to do	When to do it
_____	_____	1) “Compare Parameters”, 2 <sup>nd</sup> section 7 <sup>th</sup> box.	<b>Low Betas must be OFF</b>
_____	_____	2) “Auto Zero”, top row left side. This is the new way of doing Clocks & Scalers. When finished a box will appear saying “QPM auto zeroed”. Next click on the “Set Tolerances” button to the right of Auto Zero.	<b>Low Betas must be OFF</b>
_____	_____	3) HFU Test, top row 4 <sup>th</sup> box. First check if the HFU’s are charged on the “Status Display” page, if not issue a “QPM reset”.	<b>Low Betas must be OFF</b>
_____	_____	4) Check that there are refrigerator permits. “Status Display”, top section 5 <sup>th</sup> box. Frig permits are “DNS Frig” & “UPS Frig” in middle section.	<b>Low Betas must be OFF</b>
_____	_____	5) Plot the references and output currents of the Low Beta circuits	
_____	_____	6) Reset and close in Contactors. Second section 3 <sup>rd</sup> box is the “Reset PS” click on it, select Houses and click on “Reset PS”. To close in the contactors, second section 4 <sup>th</sup> box “Contactor On” click on it, select Houses and click on “Reset Contactor” to close them in.	
_____	_____	7) When the references are at or below 150 GeV, send a “QPM Reset” to the Low Betas, second section 1 <sup>st</sup> box. But first check if the Heaters are charged on the “Status Display” page, if not issue a QPM reset.	Sending a QPM reset will turn on the Low Beta power supplies and they will start following their references.
_____	_____	8) Reset extrema, “Reset Vres Extrema”, second section 5 <sup>th</sup> box.	Resetting the extrema, should be done whenever we turn on the low betas, after they are ramping
_____	_____	9) Turn on bulk supplies A4, B0, B1 and/or C4, D0, D1. S53 -> tev -> bulk ps	
_____	_____	10) Reset the status display, top section top 5 <sup>th</sup> box, “Status Display”.	
_____	_____	11) Activate alarms “B0ACCESS” and/or “D0ACCESS”.	
_____	_____	12) Verify Alarms screen clear.	
_____	_____	13) Reset the Tevatron abort.	
_____	_____	14) Turn on the Low Beta High Leads, F37 <38>	
_____	_____	15) Before accelerating, you will need to get T:E3PUL down to 235, +/- 5 degrees, and T:A4TP3D down to 255 +/- 8 degrees.	