



High Intensity Negative Ion Sources

Ka-Ngo Leung

Lawrence Berkeley National Laboratory

Snowmass'01

Working Group on High-Intensity Proton Sources

July 16, 2001

LAWRENCE BERKELEY NATIONAL LABORATORY



Brightness of an ion beam:

$$B = 2I / \pi^2 E_x E_y$$
$$= 2J \cdot Mc^2 / \pi^2 T_i$$




Three Types of H^- Ion Sources

- Surface conversion sources
- Volume production sources
- Hybrid production sources
(or surface plasma sources)




Two Ion Source Technologies for Neutron Science


Volume Production



Surface Conversion




Multi-Cusp Plasma Source



Constant field
strength contours


Line-cusp magnetic fields




Radial plasma density profile



The 7.5-cm-diam Multicusp H⁻ Ion Source




LAWRENCE BERKELEY NATIONAL LABORATORY



LBL 578-3522

The RF-driven Multicusp Ion Source




The RF-driven Multicusp Source






The H- Beam Pulse of the SSC Ion Source





Emittance of the SSC H⁻ Ion Beam




$d = 9 \text{ mm}$
 $r = 3 \text{ mm}$
 $V = 35 \text{ kV}$
 $I_b = 91\%$
 $I_c = 1.0 \text{ A}$


$\varepsilon = 0.06 \pi \text{ mm mr}$
divergence = 90 mr
diameter = 0.95 cm



H- Beam Current Pulse before and after the SSC RFQ



Vertical Axis : 4 mA/div
Horizontal axis : 20 μ s/div





Top trace : H⁻ current 10 mA/div
Bottom trace : electron current 500 mA/div
Horizontal axis: 20 μ s/div



SNS Ion Source Requirements

	1 MW facility	2 to 4 MW facility
Source Type	RF driven multicusp ion source, Volume produced H, Cesium enhanced, Filter magnets	
Ion	H ⁻	H ⁻
Current [mA]	35	70
Emittance [π mm mrad, norm rms]	0.15	0.2
RF frequency [MHz]	2	2
Plasma initiation	flash lamp through quartz window	
Electron suppression	magnets in extraction plate, complete deflection	
Final H ⁻ energy [keV]	65	65
Duty factor [%]	6.2	6.2
Chopping frequency [MHz]	1.188	1.188
Source Pressure [mTorr]	10	10
Lifetime [month]	1	1







RF H⁻ Source Operation Issues

- RF power supply
 - 2 MHz or 13.5 MHz
- Antenna coating
 - porcelain, wire inside quartz tubing or metal tubing inside quartz tubing
- Plasma ignition schemes
 - filament, laser, flash lamp, dual-frequency
- Cesium enhancement
 - SAES getters, oven



Antenna Coating

A good antenna coating is needed for high power cw or pulse source operations

- to withstand a high potential gradient between the plasma and the antenna
- to minimize the sputtering of antenna material
- to increase the efficiency of the ion source




Different Antennas Used in the Life-Time Tests






Quartz Tube Antenna with Titanium Tube Inside



LAWRENCE BERKELEY NATIONAL LABORATORY

Starter Filament






Ignition of the RF Plasma with a Laser Beam



LAWRENCE BERKELEY NATIONAL LABORATORY




RF Plasma Ignition with Photons





The Collar with Cesium Dispensers



Cesium Collar

LAWRENCE BERKELEY NATIONAL LABORATORY



Electron Dumping and Beam Chopping

- Surface Conversion Source

Electron dumping - low electron content

H⁻ beam chopping - by “kicking” the H⁻ beam inside the source


- Volume Production Source

Electron dumping - strong magnetic field at source exit
- micro-channel to filter the electrons


H⁻ beam chopping - modulating the extraction voltage at the micro-channel electrodes




Electron Removal (Argus Code Computation)



250 Gauss




400 Gauss



650 Gauss

transverse magnetic field


Ion Source and LEBT Schematic



The ion source with outlet and dumping electrodes is tilted by 3 deg. with respect to the LEBT axis
 Some magnet orientations are rotated into the viewing plane of this illustration
 The shape of the beam envelope is exaggerated for emphasis



H⁻ Source and LEBT System






The SNS H-LEBT System



LAWRENCE BERKELEY NATIONAL LABORATORY




The SNS H⁻ Ion Source




LAWRENCE BERKELEY NATIONAL LABORATORY



Ion-Source/LEBT Beam Current




68 mA peak current



50 mA average current



Chop Depth vs. Chop Voltage




- Chop voltage applied across deflector quadrants
- Most beam lost on LEBT diagnostic device
- Remaining beam lost in RFQ
- 2.5 kV point recorded as zero
- Easily exceeds requirements for LEBT chopper
- Guaranteed performance with LEBT and MEBT choppers is an off/on ratio of 10^{-4} .




Electron Filter for the Volume H⁻ Source

The Setup



$$T = \frac{F_{\text{holes}}}{F_{\text{hex}}} \approx 68.3\%$$


100 – 300 V





H⁻ and Electron Trajectories

KOBRA3=INP VERSION 3.3 magnetic flux density RUN 21 12 0 20
z comp. in xy plane at z=.10E-02meter iteration#
*E-4 y [m] PLOT007.HPG
color table#T1



COMMENT:electron filter


LBL Ion Beam Technology

DATE:06/01/01TIME:18:28

LAWRENCE BERKELEY NATIONAL LABORATORY




Surface-conversion Multicusp Ion Source Schematic







The LANSCE Surface Conversion H⁻ Source



LAWRENCE BERKELEY NATIONAL LABORATORY



LANSCE Prototype Source Scope Traces




H- Faraday Cup Signal 10 mA/V

Discharge 80 V, 74 A
Converter 300V, 3.1A
Source Pressure 1.1 mT

Discharge 80 V, 100 A
Converter 300V, 3.6 A
Source Pressure 1.1 mT



LANSCe Ion Source 12 % Duty Factor




Y Scale 10 mA/div

Time Base 5 msec/div




LANSCE Prototype Source Data






Interior of LANSCE Source with Cone Aperture






LANSCe H-Split Repeller






H- Split Repeller Structure




LAWRENCE BERKELEY NATIONAL LABORATORY



LANSCE Repeller Upgrade



Front-End Systems: Function



Ion Source/LEBT

Create 50-mA
H⁻ ion beam

RFQ

Accelerate beam
to 2.5 MeV

LEBT/ MEBT

Chop beam
into mini-pulses

MEBT

Match 40-mA
beam into DTL




FES Integrated Testing Facility (Test Stand #1)

RFQ

LEBT

Ion Source






FES Integrated Testing Facility (Test Stand #1)




LAWRENCE BERKELEY NATIONAL LABORATORY

Ion-Source Test Stand #2





RFQ Module #1 Connected to LEBT on 4/19/01



LAWRENCE BERKELEY NATIONAL LABORATORY